




Assembly and Operating Instructions

# ROTISSERIE



FOR OUTDOOR USE ONLY

AUSTRALIA / NEW ZEALAND


Dear customer,  
 Congratulations and thank you for choosing our appliance. We are sure you will find it a pleasure to use. Before you use the appliance, we recommend that you read through the relevant sections of this manual, which provide a description of your appliance and its functions.


To avoid the risks that are always present when you use an appliance, it is important that the appliance is installed correctly and that you read the safety instructions carefully to avoid misuse and hazards.


We recommend that you keep this instruction booklet for future reference and pass it on to any future owners.


After unpacking the appliance, please check it is not damaged. If in doubt, do not use the appliance but contact your local customer care centre.

The symbols you will see in this booklet have these meanings:

 **WARNING**  
 This symbol indicates information concerning your personal safety.


 **CAUTION**  
 This symbol indicates information on how to avoid damaging the appliance.


 **IMPORTANT**  
 This symbol indicates tips and information about use of the appliance.

 **ENVIRONMENT**  
 This symbol indicates tips and information about economical and ecological use of the appliance.


**IMPORTANT INFORMATION THAT MAY IMPACT YOUR MANUFACTURER'S WARRANTY**

Adherence to the directions for use in this manual is extremely important for health and safety. Failure to strictly adhere to the requirements in this manual may result in personal injury, property damage and affect your ability to make a claim under the BeefEater manufacturer's warranty provided with your product. Products must be used, installed and operated in accordance with this manual. You may not be able to claim on the BeefEater manufacturer's warranty in the event that your product fault is due to failure to adhere this manual.

 **IMPORTANT**  
**Important – check for any damages or marks**  
 If you find the appliance is damaged or marked, you must report it within 7 days if you wish to claim for damage/marks under the manufacturer's warranty. This does not affect your statutory rights.


 **ENVIRONMENT**  
**Information on disposal for users**

- Most of the packing materials are recyclable. Please dispose of those materials through your local recycling depot or by placing them in appropriate collection containers.
- If you wish to discard this product, please contact your local authorities and ask for the correct method of disposal.


 **CAUTION – ELECTRICAL WARNING**  
 If your barbecue incorporates an electrical component, such as a rotisserie, then it must be electrically grounded in accordance with local codes. The electric cord must be equipped with a three-pin (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-pin receptacle. Do not cut or remove the grounding pin from this plug. Keep any electrical supply cord and the fuel supply hose away from any heated surfaces.

If an external electrical source is utilised, this outdoor cooking appliance, when installed, must be electrically grounded in accordance with the local codes or, in the absence of local codes with the following:  
 USA: National Electrical Code, ANSI/NFPA 70  
 CAN: Canadian Electrical Code, CSA C22.1  
 AUS: Aust Standards Code AS:5601


**Before you start**  
 Note the tools you will need before you begin.  
 Remove any protective plastic from stainless steel components.  
 Check for damaged or missing parts, and consult your retailer if necessary.  
**Note:** To use your optional side burner while you have a rotisserie attached, unscrew the handle from the rotisserie shaft.




**Step 1**  
 Remove the plastic end cap.




**Step 2**  
 Assemble the knurled nut, counterweight, collar and handle onto the threaded end of the shaft. Tighten the wing nut on the collar once all parts are in place.



**Step 3**  
 Slide the prongs onto the shaft so they face each other.  
 Meat is secured between the prongs. Tighten the wing nuts on the prongs when the meat is in place.



**Step 4**  
 Use the counterweight to balance the load, so that the shaft and meat rotate smoothly.  
 To balance the load, loosen the knurled nut, then allow the shaft to rotate freely and come to rest. This can be done holding the shaft in your hands. The heaviest part of the meat will naturally rotate to the bottom. Now rotate the counterweight so that the weight is toward the top.  
 If the meat is very lopsided, extend the counterweight so that it is furthest from the shaft. If the meat is close to being centrally balanced, shift the counterweight so that it is closer to the shaft.  
 Retighten the nut once a reasonable balance is achieved.




**Step 1**

First, attach the motor mounting bracket to the left side of the roasting hood.

Use the bracket which has two holes diagonally apart.


The cylindrical spacers are used to separate the bracket from the hood.



**Step 2**

Then, slide the motor onto the bracket.

Note the cable is towards the top.





**Step 3**

Fit the shaft onto the roasting hood.

First insert the pointed end into the motor.


On the other end of the shaft, the groove of the collar rests directly onto the lower section of the roasting hood. You may need to loosen the wing nut on the collar to reposition it if necessary.



**Step 1**


First, attach the motor mounting bracket to the left side of the roasting hood.

Use the bracket which has one screw hole only. The bracket is secured to the barbecue with a single nut and screw. The dome shaped bump in the bracket presses into the barbecue body and prevents the bracket from rotating.




**Step 2**

Then slide the motor onto the bracket. Note the cable is towards the bottom.



**Step 3**

Attach a bracket to the right side of the barbecue body. Similarly to the other side, use a single nut and screw.




**Step 4**

Fit the shaft onto the roasting hood.

First insert the pointed end into the motor.

On the other end of the shaft, the groove of the collar rests directly onto the mounting bracket. You may need to loosen the wing nut on the collar to reposition it if necessary.





**Electrolux Warranty**

FOR SALES IN AUSTRALIA AND NEW ZEALAND  
 APPLIANCE: ELECTROLUX SPARE PARTS & ACCESSORY PRODUCTS

**This document sets out the terms and conditions of the product warranties for Electrolux Spare Parts and Accessory Products. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should there be a manufacturing defect in your Product. This warranty is in addition to other rights you may have under the Australian Consumer Law.**

**1. In this warranty:**

- (a) 'ACL' or 'Australian Consumer Law' means Schedule 2 to the Competition and Consumer Act 2010;
- (b) 'Product' means any Electrolux spare part and accessory product purchased by you and accompanied by this document;
- (c) 'ASPD' means Electrolux's Authorised Spare Parts Distributor;
- (d) 'Electrolux' is the brand controlled by Electrolux Home Products Pty Ltd of 163 O'Riordan Street, Mascot NSW 2020, ABN 51 004 762 341 in respect of Products purchased in Australia and Electrolux (NZ) Limited (collectively "Electrolux") of 3-5 Niall Burgess Road, Mount Wellington, in respect of Products purchased in New Zealand;
- (e) 'Warranty Period' means the period specified in clause 3 of this warranty;
- (f) 'you' means the purchaser of the Product not having purchased the Product for re-sale, and 'your' has a corresponding meaning.

**2. Application:** This warranty only applies to new Products, purchased and used in Australia or New Zealand and is in addition to (and does not exclude, restrict, or modify in any way) other rights and remedies under a law to which the Products or services relate, including any non-excludable statutory guarantees in Australia and New Zealand.

**3. Warranty Period:** Subject to these terms and conditions, this warranty continues for a period of 12 months in Australia and New Zealand, following the date of original purchase of the Product.

**4. Repair or replace warranty:** During the Warranty Period, Electrolux or its ASPD will, at no extra charge, subject to these terms and conditions, repair or replace any Product or parts which it considers to be defective. Electrolux may, in its absolute discretion, choose whether the remedy offered for a valid warranty claim is repair or replacement. Electrolux or its ASPD may use refurbished parts to repair your Product. You agree that any replaced Products or parts become the property of Electrolux.

**5. Travel and transportation costs:** Subject to clause 7, Electrolux will bear the reasonable cost of transportation, travel and delivery of the Product to and from Electrolux or its ASPD. Travel and transportation will be arranged by Electrolux as part of any valid warranty claim.

**6. Proof of purchase** is required before you can make a claim under this warranty.

**7. Exclusions:** You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. This warranty does not cover:

- (a) light globes, batteries, filters or similar perishable parts;
- (b) parts and Products not supplied by Electrolux;
- (c) cosmetic damage which does not affect the operation of the Product;
- (d) damage to the Product caused by:
  - (i) negligence or accident;

- (ii) misuse or abuse, including failure to properly maintain or service;
- (iii) improper, negligent or faulty servicing or repair works done by anyone other than an Electrolux authorised repairer or ASPD;
- (iv) normal wear and tear;
- (v) power surges, electrical storm damage or incorrect power supply;
- (vi) incomplete or improper installation;
- (vii) incorrect, improper or inappropriate operation;
- (viii) insect or vermin infestation;
- (ix) failure to comply with any additional instructions supplied with the Product;

In addition, Electrolux is not liable under this warranty if:

- (a) the Product has been, or Electrolux reasonably believes that the Product has been, used for purposes other than those for which the Product was intended, including where the Product has been used for any non-domestic purpose;
- (b) the Product is modified without authority from Electrolux in writing;
- (c) the Product's serial number or warranty seal has been removed or defaced.

**8. How to claim under this warranty:** To enquire about claiming under this warranty, please follow these steps:

- (a) carefully check the operating instructions, user manual and the terms of this warranty;
- (b) have the model and serial number of the Product available;
- (c) have the proof of purchase (e.g. an invoice) available;
- (d) telephone the numbers shown below.

**9. Australia:** For Products and services provided by Electrolux in Australia: Electrolux goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Product repaired or replaced if the Product fails to be of acceptable quality and the failure does not amount to a major failure. 'Acceptable quality' and 'major failure' have the same meaning as referred to in the ACL.

**10. New Zealand:** For Products and services provided by Electrolux in New Zealand, the Products come with a guarantee by Electrolux pursuant to the provisions of the Consumer Guarantees Act, the Sale of Goods Act and the Fair Trading Act. Where the Product was purchased in New Zealand for commercial purposes the Consumer Guarantee Act does not apply.

**11. Confidentiality:** You accept that if you make a warranty claim, Electrolux and its agents including ASPD may exchange information in relation to you to enable Electrolux to meet its obligations under this warranty.

**Important Notice**

Before calling for service, please ensure that the steps listed in clause 8 above have been followed.

|  |  |  |
|--|--|--|
| <p><b>FOR SERVICE</b><br/>                 or to find the address of your nearest customer care centre in Australia<br/> <b>PLEASE CALL 1300 363 640</b><br/> <small>For the cost of a local call (Australia only)</small></p> | <p><b>AUSTRALIA</b><br/>                 ELECTROLUX HOME PRODUCTS<br/>                 163 O'Riordan Street, Mascot NSW 2020<br/>                 electrolux.com.au</p>    | <p><b>FOR SPARE PARTS</b><br/>                 or to find the address of your nearest spare parts distributor in Australia<br/> <b>PLEASE 13 13 50</b><br/> <small>For the cost of a local call (Australia only)</small></p> |
| <p><b>FOR SERVICE</b><br/>                 or to find the address of your nearest authorised service centre in New Zealand<br/> <b>PLEASE CALL 0800 10 66 10</b><br/> <small>(New Zealand only)</small></p>                    | <p><b>NEW ZEALAND</b><br/>                 ELECTROLUX (NZ) Limited<br/>                 3-5 Niall Burgess Road, Mount Wellington<br/>                 electrolux.co.nz</p> | <p><b>FOR SPARE PARTS</b><br/>                 or to find the address of your nearest spare parts centre in New Zealand<br/> <b>PLEASE 0800 10 66 20</b><br/> <small>(New Zealand only)</small></p>                          |

ESP&A\_Warr\_May17

For more information on all Beefeater products, or for dimension and installation information, call into your retailer, phone or email our customer care team or visit our website:

### **AUSTRALIA**

phone: 1300 307 939

fax: 1800 356 669

email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

web: [beefeaterbbq.com](http://beefeaterbbq.com)

### **NEW ZEALAND**

phone: 0800 436 245

fax: 0800 225 088

email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

web: [beefeaterbbq.com](http://beefeaterbbq.com)

Beefeater. We are part of the Electrolux Family.  
To add a touch of professional inspiration to  
your home, visit [electrolux.com.au](http://electrolux.com.au)